

SGWAR-16

Rack Mounted
Dry Air Driven
Ozone Generator

KEY FEATURES

- Rack mounted
- Can produce 5-16 G/HR of ozone with 1-18LPM of Dry air
- Flow Meter - Standard
- 3 Year Warranty
- Weight: 12.6 KG
- Power: 350W
- CSA, ETL, UL
- 3 Year Warranty

PRODUCT DESCRIPTION

The ProMedUSA Model SGWAR-16 is a rack mounted ozone generator that can produce 5 - 16 G/HR of highly concentrated ozone with 1-18LPM of dry air as the feed gas.

This unit uses our proprietary 316 Stainless Steel and Quartz Glass Electrodes (Made in the USA) to achieve this highly concentrated level of ozone.

The SGWAR-16 requires our SGWAC-R or SWADC-R Series Controllers with a Balanced Barometer (BBM).



SGWAR-16 Ozone Generator

ProMED USA
products that REALLY work.

E*: European Version, N/A: Not Applicable, O: Optional, S: Standard

