

SGWV-DG3 Series

Ozone Generators

KEY FEATURES:

- Produces up to 23 G/HR with 8 lpm of Oxygen
- Wall Mountable
- Standard Flow Meter
- Optional:
 - Interlock (4-20 mA)
 - Mil-Spec PCB environmental protective coatings
- CSA, UL and CE, ETL
- 3 Year Warranty

ProMED USA
products that REALLY work.

PRODUCT DESCRIPTION

The SGWV-DG3 series is a wall mountable Ozone Generator that will produce up to 23 g/hr of ozone with 8 liters/min of Oxygen.

We manufacture our own ozone producing cells using our proprietary double quartz 316 Stainless Steel and Quartz technology to assure the highest concentration of ozone and many years of maintenance free operation and reliability.

Our exclusive double quartz technology in the SGWV-DG3 is tuned precisely for Oxygen only feed gas. It is ideal for ultra-pure and high concentration applications.



ProMedUSA Pte Ltd

**Asia's most trusted source for
Advanced Ozone Systems**

SGWV-DG3 SERIES SPECIFICATIONS

General	SGWV-DG3 Series
Voltage	100-120, 200-240VAC
Power Consumption	230 Watts
Ambient Temperature (C)	2 to 32 degrees
Relative Humidity	10-92%
Weight	7.9 kg
Dimensions (L X W X H) mm	465 X 315 X 165
Installation	Wallmount
Warranty	3 Years
Ozone	
Ozone Generation Process	Pulse Corona Discharge
Process Gas	Oxygen
Production on Oxygen (Refer to Graph below)	≈ 23.0 g/hr @ 8 lpm
Options	
Internal Air Pump	N/A
Adjustable Output	Standard
Interlock	Optional
Flow Meter	Standard
Oxygen Ready	Standard
Flow Switch	Standard
Safety	
CSA, UL and CE (tested by QAI Labs), ETL	

