

# SGWV-DG Series

## Ozone Generators

### KEY FEATURES:

- Produces up to 13 G/HR with 6 lpm of Oxygen
- Wall Mountable
- Standard:
  - Flow Meter
  - Adjustable Output
  - Pressure Switch
- Double Quartz Technology
- cETLus and CE
- 3 Year Warranty

**ProMED** USA  
products that REALLY work.

### PRODUCT DESCRIPTION

The SGWV-DG series is a wall mountable Ozone Generator that will produce up to 13 g/hr of ozone with 6 liters/min of Oxygen.

We manufacture our own ozone producing cells using our proprietary double quartz 316 Stainless Steel and Quartz technology to assure the highest concentration of ozone and many years of maintenance free operation and reliability.



**ProMedUSA Pte Ltd**

Asia's most trusted source for  
advanced ozone systems

# SGWV-DG SERIES SPECIFICATIONS

General	SGWV-DG Series
Voltage	100-120, 200-240VAC
Power Consumption	112 Watts
Ambient Temperature (C)	2 to 28 degrees
Relative Humidity	10-92%
Weight	3.2 kg
Dimensions (L X W X H) mm	434 X 258 X 90
Installation	Wallmount
Warranty	3 Years
Ozone	
Ozone Generation Process	Pulse Corona Discharge
Process Gas	Oxygen
Production on Oxygen (Refer to Graph below)	≈ 13.0 g/hr @ 6 lpm
Options	
Internal Air Pump	N/A
Adjustable Output	Standard
Interlock	Optional
Flow Meter	Standard
Oxygen Ready	Standard
Vacuum Switch	Standard
Safety	
CETUS and CE	

