

MODEL UV SG1200T36 MINIPRO

Professional UV Odour Removal and Disinfection Unit

Asia's most popular model for up to 200+M²

Exclusively manufactured in Canada
and the USA for ProMedUSA



Just 38 cm long!

- **OZONE OUTPUT (ACTIVATED OXYGEN): 1200 mg/hr**
- **NEGATIVE ION OUTPUT: GREATER THAN 13,000,000 IONS/CM³**
- **TiO₂ (TITANIUM DIOXIDE): THE UV SG1200 DOES NOT CONTAIN ANY TiO₂ WHICH IS POTENTIALLY CARCINOGENIC**
- **EFFECTIVE STERILIZATION: TESTED BY TUV – 96.5% KILL RATE**
- **DIMENSIONS: 38 cm X 13 cm X 16 cm; WEIGHT: JUST 3.5 kg**
- **UNIVERSAL VOLTAGE 110-220VAC; 50/60Hz; 75 WATTS**
- **WARRANTY - UNIT: 6 YEAR INTERNATIONAL WARRANTY**
- **WARRANTY – UV TUBE: 2 YEAR WARRANTY**
- **BUILT IN 9 POSITION LED ELECTRONIC TIMER IS STANDARD**
- **TREATMENT AREA: DEODORIZE, SANITIZE ROOMS and PUBLIC AREAS UP TO 200 M² or GREATER**

V5-0523

Technical Details

OVERVIEW:	The ProMedUSA Model UV SG1200T36 MiniPro Ozone Generator is designed for use as a portable, easy to use, and very effective commercial odour treatment and disinfection tool. It is ideal for use in Hotel Housekeeping, Stewarding, F&B outlets, Renovation and Restoration applications, Mould Remediation, Hospitals, Clinics, Medical Centres, Laboratories, Classrooms, Auto Detail shops, Bin Centres and for general air sanitization (Ozone kills viruses including Covid-19, germs, mould, and pathogens).
USES:	Quickly destroy odours (including mould, mildew, tobacco, foods, body odours, perfume), disinfect and freshen the air from hotel rooms, clinics, residences, restaurants, public areas, automobiles, toilets, etc.
GENERATION METHOD:	High Output, High Efficiency, Ultra Long Life (2+ Years) American Made UV Tubes. Our UV Tubes are made exclusively for ProMedUSA
OZONE OUTPUT:	1200 mg/hr
TREATMENT AREA:	The UV SG1200 MiniPro can quickly freshen a 280 M ³ space in less than 10 minutes; a 4,500 M ³ space in about an hour; and a 9,000 M ³ space in about 2 hours or less
DIMENSIONS:	38 cm long X 13 cm wide X 16 cm high; Weight is 3.2 kg
FEATURES:	The UV SG1200 MiniPro comes standard with a 9 position LED Electronic Timer (10 min, 30 min, 1,2,4,8,12,24 and 36 hours
CONSTRUCTION:	The exterior case is 4mm thick, rust proof and scratch proof, easy to clean white PVC. Inside are 2 shock mounted, 18 gauge surgical grade stainless steel inner chassis. The UV SG1200 is designed to be virtually indestructible and will look clean and fresh for years.
ELECTRICAL:	110-120VAC 60Hz, or 220-240V 50Hz, 78 watts maximum
6 YEAR WARRANTY:	The UV SG1200 MiniPro has an international 6 Year Warranty against all defects in materials and workmanship. Our Made in USA UV Tubes are guaranteed for 2 full years .
UV TUBE LIFE EXPECTANCY AND COST:	Generally, 2 to 3 Years. Replacement UV Tube cost is only \$187.50. The UV SG1200 has two ozone producing UV Tubes inside.
MAINTENANCE:	Easy, Simple, and Minimal. Just replace the rear filter when dirty (usually every 3 months or so) and throw it away. It takes just 1 minute and you can do it yourself.