

**UV SG1200T36 MINIPRO  
COMMERCIAL - PORTABLE  
UV OZONE GENERATOR**

**OVERVIEW:**

The ProMedUSA UV SG1200T36 MINIPRO ozone generator is designed for use as an adjustable output commercial odour treatment tool. It is ideal for use in hotel housekeeping, stewarding, F&B, restoration use, mold remediation, medical centres, laboratories, clinics, bin centres and air sanitization (ozone kills germs, viruses including H1N1, H7N9, HFMD, E.Coli, Salmonella, MSRA, Staph, etc.).



Just 38 cm long!

**This is the SMALLEST and LIGHTEST FULL POWERED ozone generator available on the market today.** They are exclusively made in Canada for ProMedUSA with the highest quality components to extremely rigorous standards. Our UV generating tubes are made in the United States exclusively for us.

**USES:**

Quickly destroy odours and freshen the air (including mould, mildew, tobacco, foods, viruses, germs, bacteria) from hotel rooms, clinics, homes, public spaces.

**GENERATION METHOD:**

High Output, Hi-Efficiency Ultra Long Life (2+ Years) American made UV Tubes

**OZONE OUTPUT:**

1200 MG/HR

**EFFECTIVENESS:**

The SG1200 can easily freshen a 280 M<sup>3</sup> space in 10 minutes, and a 4,400 M<sup>3</sup> space in about 1 to 2 hours.

**CONTROLS:**

On/Off rocker switch, standard LED 9 position electronic timer (Always On, 10 min, 30 min, 1,2,4,8,12,18 and 36 hours). Other custom options are available.

**DIMENSIONS and WEIGHT:**

38 cm Long X 13 cm Wide X 16 cm High and only 3.2 KG.

**CONSTRUCTION:**

4 mm thick white PVC external case over 18 gauge Stainless Steel shock mounted inner chassis. The UV SG600 is virtually indestructible and always look clean and fresh for years

**ELECTRICAL:**

220-240V 50HZ, 78 Watts Maximum (120V 60hz also available)

**UV TUBE LIFE EXPECTANCY and REPLACEMENT COST:**

Generally over 24 - 36 months of continuous use. Replacement tube cost is only \$150 per tube (2 needed)

**MAINTENANCE:**

Minimal – just clean the rear filter usually every 2-3 months, and wipe the UV Tube clean once per year. Entire process takes only 3 minutes!

**WARRANTY:**

**The UV SG1200 is FULLY GUARANTEED INTERNATIONALLY against all defects in materials and workmanship for 6 YEARS. Our Made in USA UV Tubes are guaranteed for a full 2 YEARS.**

# MODEL UV SG1200T36 MINIPRO

## Professional Ozone Generator

Exclusively manufactured in Canada  
only for ProMedUSA!



Just 38 cm long!

- **OZONE OUTPUT:** 1200 MG/HR
- **DIMENSIONS:** 38 CM X 13 CM X 16 CM; **WEIGHT:** JUST 3.2 kg
- **POWER:** 220/240V 50hz, 78 WATTS
- **WARRANTY - UNIT:** 6 YEAR INTERNATIONAL WARRANTY
- **WARRANTY – UV TUBE:** 2 YEAR WARRANTY
- **BUILT IN LED ELECTRONIC TIMER:** ALWAYS ON, 10 MIN, 30 MIN, 1 HR, 2 HR, 4 HR, 8 HR, 12 HR, 24 HR AND 36 HR
- **CAPABILITY:** CAN EASILY FRESHEN THE AIR IN A ROOM OF UP TO 1200 FT<sup>2</sup> / 120 M<sup>2</sup> or 9,600 FT<sup>3</sup> / 280 M<sup>3</sup> IN ABOUT 10 MINUTES

UV SG1200 V10.0