

MODEL UV SG600T36 MINIPRO

Professional UV Odour Removal and Disinfection Unit

Asia's most popular model for up to 100M²+

Exclusively manufactured in Canada
and the USA for ProMedUSA



Just 38 cm long!

- **OZONE OUTPUT (ACTIVATED OXYGEN): 600 mg/hr**
- **NEGATIVE ION OUTPUT: GREATER THAN 13,000,000 IONS/CM³**
- **EFFECTIVE STERILIZATION: TESTED BY TUV – 96.5% KILL RATE**
- **DIMENSIONS: 38 cm X 13 cm X 16 cm; WEIGHT: JUST 3 kg; 55 Watts**
- **WARRANTY - UNIT: 6 YEAR INTERNATIONAL WARRANTY**
- **WARRANTY – UV TUBE: 2 YEAR WARRANTY**
- **BUILT IN 9 POSITION LED ELECTRONIC TIMER IS STANDARD (10 min, 30 min, 1 hr, 2 hr, 4 hr, 8 hr, 12 hr, 24 hr 36 hr)**
- **TREATMENT AREA: DEODORIZE, SANITIZE and DISINFECT ROOMS and PUBLIC AREAS UP TO 100 M² or GREATER**

ProMedUSA Pte Ltd • 111 North Bridge Road • #08-27 Peninsula Plaza • Singapore 179098
Tel: (65) 6836-9665 • www.promedusa.us • sales@promedusa.us

SINGAPORE • MALAYSIA • INDONESIA • PHILIPPINES • BRUNEI • THAILAND • CAMBODIA • MYANMAR • VIETNAM • CHINA

Technical Details

Overview: The ProMedUSA Model UV SG600T36 MiniPro Ozone Generator is designed for use as a portable, easy to use, and very effective commercial odour treatment and disinfection tool. It is ideal for use in Hotel Housekeeping, Stewarding, F&B outlets, Renovation and Restoration applications, Mould Remediation, Hospitals, Clinics, Medical Centres, Laboratories, Classrooms, Auto Detail shops, Bin Centres and for general air sanitization (Ozone kills viruses including Covid-19, germs, mould, and pathogens).

Uses: Quickly destroy odours (including mould, mildew, tobacco, foods, body odours, perfume), disinfect and freshen the air from hotel rooms, clinics, residences, restaurants, automobiles, toilets, public areas, etc.

Generation Method: High Output, High Efficiency, Ultra Long Life (2+ Years) American Made UV Tube. Our UV Tubes are made exclusively for ProMedUSA.

Ozone Output: 600 mg/hr

Treatment Area: The UV SG600 MiniPro can quickly freshen a 100 M³ space in less than 10 minutes; a 2,200 M³ space in about an hour; and a 4,500 M³ space in about 2 hours or less

Dimensions: 38 cm long X 13 cm wide X 16 cm high; Weight is 3 kg

Features: The UV SG600 MiniPro comes standard with a 9 position LED Electronic Timer (10 min, 30 min, 1,2,4,8,12,24 and 36 hours)

Construction: The exterior case is 4mm thick, rust proof and scratch proof, easy to clean white PVC. Inside are 2 shock mounted, 18 gauge surgical grade stainless steel inner chassis. The UV SG600 is designed to be virtually indestructible and will look clean and fresh for years.

Electrical: 110-120VAC 60Hz, or 220-240V 50Hz, 55 watts

6 Year Warranty: The UV SG600 MiniPro has an international **6 Year Warranty** against all defects in materials and workmanship. Our Made in USA UV Tubes are guaranteed for **2 full years**.

UV Tube Life Expectancy and Cost: Generally, 2 to 3 Years (17,000 hours). Replacement UV Tube cost is only \$225.00. The UV SG600 has one ozone producing UV Tube

Maintenance: Easy, Simple, and Minimal. Just replace the rear filter when dirty (usually every 4 months or so) and throw it away. It takes just 1 minute and you can do it yourself.