

**UV SG600T36 MINIPRO
COMMERCIAL - PORTABLE
UV OZONE GENERATOR**

OVERVIEW:

The ProMedUSA UV SG600T36 MINIPRO ozone generator is designed for use as an adjustable output commercial odour treatment tool. It is ideal for use in hotel housekeeping, stewarding, F&B, restoration use, mold remediation, medical centres, laboratories, clinics, bin centres and air sanitization (ozone kills germs, viruses including H1N1, H7N9, HFMD, E.Coli, Salmonella, MSRA, Staph, etc.).



Just 38 cm long!

This is the SMALLEST and LIGHTEST FULL POWERED ozone generator available on the market today. They are exclusively made in Canada for ProMedUSA with the highest quality components to extremely rigorous standards. Our UV generating tubes are made in the United States exclusively for us.

USES:

Quickly destroy odours and freshen the air (including mould, mildew, tobacco, foods, viruses, germs, bacteria) from hotel rooms, clinics, homes, public spaces.

GENERATION METHOD:

High Output, Hi-Efficiency Ultra Long Life (2+ Years) American made UV Tube

OZONE OUTPUT:

600 MG/HR

EFFECTIVENESS:

The SG600 can easily freshen a 140 M³ space in 10 minutes, and a 2,200 M³ space in about 1 to 2 hours.

CONTROLS:

On/Off rocker switch, standard LED 9 position electronic timer (Always On, 10 min, 30 min, 1,2,4,8,12,18 and 36 hours). Other custom options are available.

DIMENSIONS and WEIGHT:

38 cm Long X 13 cm Wide X 16 cm High and only 3 KG.

CONSTRUCTION:

4 mm thick white PVC external case over 18 gauge Stainless Steel shock mounted inner chassis. The UV SG600 is virtually indestructible and always look clean and fresh for years

ELECTRICAL:

220-240V 50HZ, 40 Watts Maximum (120V 60hz also available)

UV TUBE LIFE EXPECTANCY and REPLACEMENT COST:

Generally over 24 - 36 months of continuous use. Replacement tube cost is only \$150 per tube (1 needed)

MAINTENANCE:

Minimal – just clean the rear filter usually every 2-3 months, and wipe the UV Tube clean once per year. Entire process takes only 3 minutes!

WARRANTY:

The UV SG600 is FULLY GUARANTEED INTERNATIONALLY against all defects in materials and workmanship for 6 YEARS. Our Made in USA UV Tubes are guaranteed for a full 2 YEARS.

MODEL UV SG600T36 MINIPRO

Professional Ozone Generator

Asia's most popular model!

Exclusively manufactured in Canada
only for ProMedUSA!



Just 38 cm long!

- **OZONE OUTPUT:** 600 MG/HR
- **DIMENSIONS:** 38 CM X 13 CM X 16 CM; **WEIGHT:** JUST 3 kg
- **POWER:** 220/240V 50hz, 40 WATTS
- **WARRANTY - UNIT:** 6 YEAR INTERNATIONAL WARRANTY
- **WARRANTY - UV TUBE:** 2 YEAR WARRANTY
- **BUILT IN LED ELECTRONIC TIMER:** ALWAYS ON, 10 MIN, 30 MIN, 1 HR, 2 HR, 4 HR, 8 HR, 12 HR, 24 HR AND 36 HR
- **CAPABILITY:** CAN EASILY FRESHEN THE AIR IN A ROOM OF UP TO 600 FT² / 60 M² or 4,800 FT³ / 140 M³ IN ABOUT 10 MINUTES

UV SG600 V10.0