

ProMedUSA NOVITA A5 Air Purifier

Up to 80 SqM Coverage

A5.

**MOST COMPACT
MOST POWERFUL**

BREATHE WELL · BREATHE SAFE
Powered by PuriPRO® Filter

*** AIR PURIFIER IN ITS CLASS * 272.6 M³/HR AHAM CADR SMOKE * 400 M³/HR HIGH AIR FLOW RATE**

Breathe Well, breathe Safe with novita PuriClean™ Air Purifier A5, a well-rounded and cost-effective air purifier to keep your indoor air quality in check! Powered by H13 PuriPRO® filtration system and semi-permanent built-in ionizer that emits more than 20 Million/cm³ of negative ions to keep 99.97% of airborne allergens and germs at bay. Driven by DC Brushless Motor System, A5 features AHAM Smoke CADR rating of 272.6 m³/hr and high air flow rate of 400 m³/hr with coverage area up to 861 ft². Loaded with practical functions like PM2.5 sensor and display, smart auto mode to optimize your indoor air quality effortlessly! Excelling in all areas in its class to meet your discerning needs, this compact and energy-efficient A5 is undoubtedly a must-have!

AIR PURIFIER A5

Speed Setting:	Sleep	I	II	III
Air Flow Rate:	50 m ³ /hr	130 m ³ /hr	230 m ³ /hr	400 m ³ /hr
Recommended Coverage ^Δ :	108 ft ²	280 ft ²	495 ft ²	861 ft ²
Noise Level:	Up to 57 dBA			
Power Consumption:	3.3 to 52 Watts			
Voltage / Frequency:	220V - 240V / 50Hz / 60Hz			
Net Weight:	4.1 Kg			
Dimension (W x D x H):	340 mm x 175 mm x 434 mm			
AHAM AC-1-2020 CADR Smoke (PM0.1 to 1.0):	272.6 m ³ /hr			
GB/T18801-2015 CADR Particulate (PM2.5):	337 m ³ /hr			
Filter Unit Capacity ^Δ :	PuriPRO® Filter Suggested Replacement 24 Months ^Δ (Approx. 6,000 Hours)			
PuriPRO® Filtration System:	Step 01: Granular Activated Carbon Filter Step 02: Cool Catalyst Filter Step 03: H13 HEPA Filter* Step 04: Built-In Ionizer (Semi-Permanent)*			
Negative Ions Density [†] :	Up to 20 Million/cm ³			

EXCLUSIVE DISTRIBUTOR

ProMedUSA Pte Ltd

111 North Bridge Road ♦ #08-27 Peninsula Plaza ♦ Singapore 179098
(65) 6836 9665 ♦ Sales@promedusa.us ♦ www.promedusa.us