

Professional Air Dryer

ProMedUSA SGWAD-12 General Product Information	
Voltage	Universal Voltage 100-240VAC, 50/60hz
Power Consumption	200 Watts
Ambient Temperature	2 -40C
Ideal Operating Relative Humidity	80% RH at 31C 50% RH at 40C
Dimensions	435 X 258 X 78
Weight	4.5 kg
Warranty (T&C Apply)	3 Years
Dry Air Production	
Process	2 automatically recharged alumina desiccant cylinders
Feed Gas	Outside air
Dry Air Production	12LPM at 25C and 75% RH
Output	Suction Driven from Ozone Generator
Features	
Capability	Up to 6 SGWV-0.5 Ozone Generators or 2 SGWV-K4 Ozone Generators
Mil-Spec PCB Coating	Optional
Certifications	cETLus and CE



The SGWAD-12 is a wall mountable Air Dryer that will produce up to 12 liters/minute of dry air, and can be designed to be able to operate 24/7.

It has been engineered to provide dry air as the feed gas for up to 6 of our model SGWH-0.5 Ozone Generators or 2 of our WGWV-K4 Ozone Generators (all depending upon environmental conditions of course).

Air drying is accomplished with 2 automatically recharged alumina desiccant cylinders.

The dry air output is suction (vacuum) driven from the ozone generator.