

Professional Ozone Generator

Asia's most trusted source since 2006 for advanced ozone systems

ProMedUSA SGWV-DG3 General Product Information	
Voltage	Universal Voltage 100-240VAC, 50/60hz
Power Consumption	230 Watts
Ambient Temperature	2 -40C
Relative Humidity	10 – 92% (non-condensing)
Dimensions	466 X 316 X 102
Weight	7.9 KG
Warranty (T&C Apply)	3 Years
Ozone Production	
Generation Process	Pulse Corona Discharge
Electrode Type	Sealed Proprietary (Made in USA) 316 SS and Double Quartz
Feed Gas	Oxygen Only
Production on O2	~ 22 gm/hr with 6LPM O2 flow
Production on Dry Air	N/A
Features	
10 Position Adjustable Output	Standard
Mil-Spec PCB Coating	Optional
Flow Meter	Digital - Standard
Vacuum Switch	Standard
Internal Air Pump	N/A
Oxygen Ready	Yes - Standard
4-20mA Input	Optional
Interlock	Optional
Flow Switch	Standard



The SGWV-DG3 series is a wall mountable Ozone Generator that will produce up to 22 g/hr of ozone with 6 liters/min of Oxygen.

We exclusively manufacture our own sealed ozone producing cells using our proprietary 316 Stainless Steel and Double Quartz technology for the SGWV-DG3 that is tuned precisely for an Oxygen only feed. This assures ultra-pure ozone and high concentration.

Our fans are rated at a 100,000 hour life guaranteeing many years of maintenance free operation.

