

SGWV-K10 Series

Ozone Generators

- Produces up to 10 G/HR with dry air
- LED Flow Meter is Standard
- Adjustable Output
- Wall Mountable
- Universal Voltage
- Just 220 Watts
- Optional: Interlock
- cETLus and CE
- 3 Year Warranty

ProMED USA
products that REALLY work.

PRODUCT DESCRIPTION

The SGWV-K10 series is a wall mountable Ozone Generator that will produce up to 10 g/hr of ozone with an air dryer (SGWAD-30) providing 16 lpm of pure dry air

We manufacture our own ozone producing cells using 316 Stainless Steel and Quartz to assure the highest concentration of ozone and many years of maintenance free operation and reliability.

The SGWV-K10 Series is designed to run 24/7 for years and has our 3 year international warranty.



ProMedUSA Pte Ltd

**Asia's most trusted source for
Advanced Ozone Systems**

SGWV-K10 SERIES SPECIFICATIONS

General	SGWV-K10 Series
Voltage (Universal)	100-120, 200-240VAC
Power Consumption	220 Watts
Ambient Temperature (C)	2 to 40 degrees
Relative Humidity	10-92%
Weight	8.7 kg
Dimensions (L X W X H) mm	465 X 315 X 165
Installation	Wallmount
Warranty	3 Years
Ozone	
Ozone Generation Process	Pulse Corona Discharge
Process Gas	Dry Air
Production on Dry Air (Refer to Graph below)	≈ 10.0 g/hr @ 16 lpm
Options	
Internal Air Pump	N/A
Adjustable Output	Standard
Interlock	Optional
Digital Flow Meter	Standard
Oxygen Ready	Dry Air Only
Flow Switch	Standard
Safety	
CETUS, ETL and CE	

